

---

# Portal User Guide

Viewer 2.0



**July 2017**

Get the latest version of the User Guide at [help.propelleraero.com](http://help.propelleraero.com)

<b>Getting started</b>	<b>5</b>
How to get help	5
Glossary	5
Access your portal	8
Setting up a new portal	8
Granting Site access to new Site Users	8
Batch user management	9
Granting access to new Admin Users	10
Activating a user account	10
Customise your portal	11
Managing the appearance of your portal	11
Managing billing and viewing processing requests	12
Change your license	13
Change your billing email address	14
View your processing requests	14
Managing your user details	14
<b>Navigating in the viewer</b>	<b>15</b>
Turning on the Demo Sites	15
Exploring the different views	16
Toggle between views	17
Navigating in the Map View	17
Navigating in the Photo View	18
Using the Annotations Tab	19
Using the Layers Tab	21

Changing the Viewer settings	22
Creating a Site	23
Creating a new site	23
Adding a design surface to your new Site	23
<b>Uploading data</b>	<b>24</b>
Uploading drone survey data	24
Uploading source photos	24
Uploading photos to a dataset	25
Enter ground control point data	26
Guidelines for ground control point files	27
GCP rows and columns	27
Decimal places	27
Uploading data with an AeroPoint survey	28
Uploading data without ground control points	28
Upload status	29
Service Level Agreement	29
Uploading custom data	30
Design surface (DXF, DWG, OrthoTIFF)	30
Overlay (KMZ, KML, GeoJSON, CZML)	30
<b>Downloading data</b>	<b>31</b>
Where to download data	31
Coordinate Reference System and Projection of downloaded data	32
<b>Downloads from the Layers Tab</b>	<b>32</b>
Orthophoto (.JPG )	33
DEM (.TIF )	33
TIN (.DXF) Surface 3D Faces	34

Point Cloud (.LAZ)	34
3D Model (.OBJ )	35
.TIF Orthomosaic	36
Custom .KML and .KMZ files	36
<b>Making measurements</b>	<b>37</b>
Annotations	37
Tools for creating Annotations	37
Editing and Deleting Annotations	38
Measurement Tools	38
Site Tools	39
Point Tools	39
Line Tools	39
Volume and Area Tools	40
Tools for exporting data	43

# Getting started

## How to get help

You can access support from the following places:

- [help.propelleraero.com](http://help.propelleraero.com) for the Knowledge Centre and the latest User Guide
- Inside the Portal: go to Help > Send a Message (sends a message in the browser app and copies [support@propelleraero.com](mailto:support@propelleraero.com))







- [support@propelleraero.com](mailto:support@propelleraero.com) for questions you can't answer from the above

## Glossary

In this User Guide we refer to Licenses, Portals, Sites, Datasets, Data objects, Annotations, Users, and Admin Users. Here's an explanation of what these terms mean to Propeller.

<b>License</b>	When you purchase access to the Propeller portal, your License specifies how many Sites (geographic locations) and Datasets (drone flights) you can add to your Portal as well as pricing information.
<b>Portal</b>	Your portal is the website created for you at <a href="http://&lt;your-portal-name&gt;.prpellr.com">http://&lt;your-portal-name&gt;.prpellr.com</a>
<b>Site</b>	A Site is where your drone flight data is stored. One Site represents one geographic location with one or more drone flight Datasets.

	 <p>On a Site with multiple drone flights, you can compare drone flight data over time using the timeline tool at the bottom of the portal. You can also compare elevation, area and volume measurements across multiple drone flights using the Annotation and measurement tools.</p>
<p><b>Dataset</b></p>	<p>One Dataset includes the results of a single drone flight, created when you select “Upload Data” and upload your photographs. The Dataset includes the photographs that were part of the flight as well as the outputs we create from that data (the 3D model, point cloud and other downloadable items).</p> 
<p><b>Data object</b></p>	<p>A Data object is an individual output</p>

	<p>belonging to a complete dataset. For example, it is one 3D model, point cloud or other downloadable item.</p>
<b>Annotation</b>	<p>Annotations are point, line or area mark-ups on your Site Map.</p> <p>They can be created in either the Map Pane or the Photo Pane using the measurement tools.</p>  <p>Annotations are displayed as a list in the Annotations Tab. Clicking on an Annotation displays measurement information about the elevation, length and area/volume in the marked-up region.</p> 
<b>Site User</b>	<p>Site Users are granted access to specific Sites in the Portal. They can view, edit or manage those Sites, depending on the permission they were granted. Permission to manage a Site includes permission to share the Site with new Site Users.</p>

## **Admin User**

Users with the ability to manage the organisation's portal are known as "Admin Users". These users can create and manage all Sites, configure the portal, and share Sites with new users.

## **Access your portal**

### **Setting up a new portal**

When you purchased a License, we collected the following details from you:

- Organization name
- Your preferred portal address
- The email address of the first portal user

The email address you provide will be sent an activation link inviting them to create a Propeller account to view the portal. (If the email address is already associated with a Propeller account, the email they receive will contain a link to the portal, but no activation link.)


After the email-address owner follows the activation link, Propeller will grant "Admin User" access to this email address. "Admin Users" can configure the organization's portal, manage billing and create and manage all Sites in the portal.

### **Granting Site access to new Site Users**

New Site Users can be added to a Site in Viewer 2.0 by navigating to the Site then clicking on the sharing button. Adding a user and selecting view, edit or manage permissions will send them an activation email, inviting them to create an account and password to log in to the Portal.

Ask the user to add [support@propelleraero.com](mailto:support@propelleraero.com) to their email safelist to ensure they receive the email.





## Batch user management

An alternative way to manage user permissions is by navigating to <http://<yoursite>.prpeller.com/p/settings/permissions>.

### USERS & PERMISSIONS

#### Manage users & permissions

Invite new user

Demo site access

First Name / Last Name	Email	Date Joined ↑	Access	Owns
John Frost	<a href="mailto:john@propelleraero.com.au">john@propelleraero.com.au</a>	April 28, 2017	1 site	1 site
Richard Hordern-Gibbings	<a href="mailto:richard@propelleraero.com.au">richard@propelleraero.com.au</a>	July 15, 2015	0 sites	0 sites
Demo1 User	<a href="mailto:demo1@propelleraero.com.au">demo1@propelleraero.com.au</a>	November 5, 2014	0 sites	0 sites
Propeller Aerobotics	<a href="mailto:propeller@propelleraero.com.au">propeller@propelleraero.com.au</a>	November 5, 2014	0 sites	0 sites

Displaying all 4 users

From here, you can select a single user and manage their permissions across all of your Sites. This is an alternative to selecting the Sharing button, which allows you to

manage users across a single Site. In this example, the User Propeller Aerobotics was selected, and given Manage access to all Sites in the portal.


USERS & PERMISSIONS / PROPELLER AEROBOTICS

### Permissions for Propeller Aerobotics

Demo site access				
Site	Date Created	View <input type="checkbox"/>	Edit <input type="checkbox"/>	Manage <input checked="" type="checkbox"/>
Empty Site 3	July 17, 2017	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Empty Site 2	July 17, 2017	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Test Aggregates	July 12, 2017	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

## Granting access to new Admin Users

If you would like additional Admin Users:


- Add the new user's email to a Site using the sharing button .
- The new user will receive an activation email with an activation link to set up their account..
- After the new user has activated their account, they will have Site User permissions.
- The portal owner should send an email to [support@propelleraero.com](mailto:support@propelleraero.com) requesting that the new user be added to the list of "Admin Users".

## Activating a user account

When your portal is created, the portal owner will receive an email from [support@propelleraero.com](mailto:support@propelleraero.com) inviting them to create an account and password.

- Please make sure [support@propelleraero.com](mailto:support@propelleraero.com) is added to your email safe list so that you can receive this email.
- Follow the activation link and enter a name and password to set up your account.
- Until the activation link is followed, there will be no account associated with that email address, and the reset password link will not work.

- If, after activating your account, you cannot see any Sites in the portal, try logging out and logging in again using the Account menu in the top right hand corner of the portal.




- If they still cannot see the Site, email [support@propelleraero.com](mailto:support@propelleraero.com) and include the name of the Site and the email address that should have access to it.

## Customise your portal

### Managing the appearance of your portal

You can change the color scheme of your portal and the logo that appears in the top left hand corner.

Navigate to Account > Configure Portal




Here you can upload a new logo design and enter the hex code of the colors you would like to appear as the background and highlight colors on your portal



The screenshot shows a configuration interface with three sections: 'Background colour' with a yellow input field containing '#ffdd33', 'Accent colour' with a black input field containing '#000000', and 'Logo' with a placeholder image of a propeller and the text 'Choose logo'. Each section has a help icon (question mark) to its right.

## Managing billing and viewing processing requests

You can view your License information and billing history by navigating to Account > Billing in the top right of the Viewer.



## BILLING

### Manage your subscription and view invoice history

Your Plan

Plan: **Starter**

Change plan

You have **\$0** credit remaining.

Current billing period: **13 Jun - 13 Jul 2017**

You're using **22** data sets of **3**

Next payment

Plan payment: **\$0.00 USD**

Outstanding amount: **\$0.00 USD**

Total amount due: **\$0.00 USD + GST** (will be paid **13 Jul 2017**)

Payment method

No payment method is currently setup

Add payment method

Billing e-mail address

Billing E-mail Address:

support@propelleraero.com.au

Update e-mail

Processing This Period

No outstanding processing requests

Invoice History

Transaction Date	Period	Amount	Paid
13 Jun 2017	13 Jun - 13 Jul 2017	\$0.00	✓
29 Jul 2016	29 Jul - 29 Aug 2016	\$55.00	Not paid
29 Jun 2016	29 Jun - 29 Jul 2016	\$55.00	Not paid
29 Jun 2016	29 Jun - 06 Jul 2016	\$0.00	✓

### Change your license

You can change your License by contacting [sales@propelleraero.com](mailto:sales@propelleraero.com).

## Change your billing email address


You can update your billing email address under Account > Billing.

## View your processing requests

You can view the status of your recent processing requests in Account > Billing.

## Managing your user details

Navigate to Account > My Details, using the menu in the top right of the Viewer.



### MY DETAILS

#### Manage your account details

**Personal Details**  
  

**First name:**

**Last name:**

These settings are managed by your third party authentication provider.

**Email Address**  
  

**Email address:**

This setting is managed by your third party authentication provider.


If you signed in using Google to authenticate your email address, the option to change your name and email address will be unavailable. You can change these details if you log in using your email address and password.

## Navigating in the viewer

You can explore the viewer after selecting a Site. If you have not yet created a Site, you can explore the Viewer using the Demo Sites.

### Turning on the Demo Sites

The Demo Sites are listed in the left hand side of the Viewer, under "Select a site..."



After clicking the "Select a site..." button, it will change to "Search for a site" and the Demo Sites will be listed. Select the Harbour Development Demo to begin exploring the Viewer.



If you cannot see the Demo Sites, your portal settings may have the Demo Sites option turned off . You can turn the Demo Sites on by navigating to Account > My Details and selecting "Show Demo Sites".



## Exploring the different views

The Viewer has three different views:


### Map View (turned on by default)

The Map View allows you to create Annotations which can be exported as a CSV.

In the Map View you can view the Orthophoto, Terrain, Point Cloud, Camera Positions and Overlays by switching on these options in the Layers Tab.

While Terrain is turned off, the Map View shows the Easting, Northing and Elevation of the WGS84 Ellipsoid at the location indicated by the cursor. The WGS84 Ellipsoid is a smooth surface and you may notice these heights generally do not change much as you move the cursor.

While Terrain is turned on, the Map View shows the Easting, Northing and Elevation of the current dataset at the location indicated by the cursor. This Elevation is a Geoid height, and is measured relative to the height datum supplied when you uploaded the current dataset. This is the height you are interested in when making Annotations and measuring elevations, and it may differ substantially from the WGS84 Ellipsoid height.






## Photo View


The Photo View allows you to create Annotations which can be exported as a PDF.

In the Photo View you can view and download original source photos.



## Annotations and Layers View

(The Annotations and Layers View is shown to the left of the Map View. Both the Map View and Photo View are visible.)



## Toggle between views

You can toggle between the Map View and Photo View, or view both at the same time, using the toggle buttons at the top right of the Viewer.



You can toggle the Annotations and Layers View on or off using the Controls tab at the left hand side of the screen.




## Navigating in the Map View

Left click + drag over map to translate / move under current view

Click the scroll wheel + drag over map  
(or click and drag the gyroscope) to  
enter free orbit



Right click (or Ctrl + click) + drag over  
map or scroll to zoom in and out.




Click the home button to reset view




## Navigating in the Photo View

Double click on a photo in the  
Thumbnails tab, or (with the Map View  
open) double click on part of the Map  
View, to display a photo in the Photo  
View.



Left click + drag to move translate /  
move the photo in Photo View


You can download individual photos by  
selecting the Photo Options button in  
the top right hand corner of the Photo  
View.



## Using the Annotations Tab

In the Annotations tab, click on the name of an annotation to display the measurements for that annotation.

The checkbox next to each Annotation allows you to turn on/off viewing the Annotation in the Map View and Photo View.



Click on the star icon next to an Annotation to "Promote to Site Level". Promoting an Annotation to Site Level makes the Annotation available to all datasets on a particular Site, not only the dataset in which it was created.



Click on the name of the 'Template' to change the measurement options which are available. This example shows the 'Stockpile Template'.

Stockpile7

Template: Stockpile Template

Location

Type text...

Smart Volume

Fill

Net

Cut

-118.394 m<sup>3</sup>

1 904.81 m<sup>3</sup>

2 023.20 m<sup>3</sup>

Material

Select...

Armour Rock Size

Select...

+ Add/Edit Items

Click the dropdown menus to change the measurement option in each part of the template.

Smart Volume

Reference Level Volume

Volume Compare

Cut

0.041 m<sup>3</sup>

+ Add/Edit Items


Click on '+Add/Edit Items' to change the measurement options that are available in the selected template and save them as a custom template.

+ Add/Edit Items

propelleraero.com // page 20

## Using the Layers Tab


From the Layers tab, you can turn on/off the Orthophoto, Terrain Contours or Point Cloud view, and any custom KMZ files that you uploaded.



Click on Downloads to access downloadable data items including the 3D model, DEM, Contours, Ortho TIF, LAZ, DXF, Ortho JPG files, and any custom KMZ files you uploaded.

The coordinate reference system and projection of your downloads is indicated next to the name of each downloadable item as an EPSG code. You can look up the EPSG code at [www.epsg.io](http://www.epsg.io) to get the details of the coordinate reference system and projection of the data item. By default, this will be the same as the EPSG code specified when uploading your survey data.

The KMZ file is always in EPSG 3875: WGS84 Spherical Mercator (aka Web Mercator). This is defined by the file format so cannot be changed.



You can drag and drop a custom layer file into the viewer using the upload layer button. This will allow you to view a customer layer as an overlay.

Accepted file formats are KML, KMZ, GeoJSON and CZML.

If you are uploading a KML or KMZ file, you must have the following settings for the polylines within the KML files, to ensure the Viewer can render it correctly:

- Altitude: Clamp to ground
- The file size must be less than 3 MB.

+ Upload Layer

## Changing the Viewer settings

Select the settings button in the top right of the Viewer



Here you can change:


- The units displayed in the bottom right of the Photo View from Metres to US Survey Feet or International Feet
- The gradient unit from Degrees to percent or ratio
- The projection from Geographic to UTM, or to a specific EPSG code or proj.4 definition string
- The Base map
- Render quality, to change the speed the viewer loads.

<b>Linear Unit</b>	<b>Base Map</b>
<input checked="" type="radio"/> Metre	<input checked="" type="radio"/> Road
<input type="radio"/> U.S. Survey Foot	<input type="radio"/> Satellite
<input type="radio"/> International Foot	<input type="radio"/> None
<b>Gradient Unit</b>	<b>Render Quality</b>
<input type="radio"/> Degrees	<input type="radio"/> Low
<input checked="" type="radio"/> Percent	<input checked="" type="radio"/> Normal
<input type="radio"/> Ratio	<input type="radio"/> High
<b>Projection</b> <a href="#">edit</a>	<b>Advanced</b>
Geographic	<input type="checkbox"/> Debug mode
	<a href="#">About...</a>


## Creating a Site

### Creating a new site


You can create a new site by navigating to "Select a site..."



Then select "Create a new site" in the top left of the Viewer.



Enter a Site name at the prompt, and choose whether to add a Design Surface.



Information about the requirements for Design Surfaces can be found in ["Adding a design surface to your new site"](#).

### Adding a design surface to your new Site

You can add a design surface by providing a georeferenced DXF, DWG or OrthoTIFF file that sits within your site boundaries.

Design surfaces allow you to make measurements against the features in the uploaded file, for example using the Volume Compare measurement tool.


Please email the file to [data@propelleraero.com](mailto:data@propelleraero.com) with the units (US International Feet, US Survey Feet, or metres) and the coordinate system of the projection.

# Uploading data

## Uploading drone survey data


### Uploading source photos

After entering details about your ground control, you can select source photos to upload for processing.




Select at least 10 source photos. All photos must have compatible geotags.

The next screen will alert if these requirements have been met.



Our image processing software requires at least 10 photographs with approximately 70-80% overlap to reconstruct a 3D model. The uploader checks that you have at least ten photographs with geotags, so you won't get a warning about insufficient overlap until later in processing.

All photos must have compatible geotags. This information is stored in the EXIF header data of the photographs. If you collected data with a drone that does not add geotag





information to the photographs, you may need to use software like exiftool to add the geotag information back into the photographs, before you can upload data.

## Uploading photos to a dataset

Choose the Site where you want to upload your dataset.

We recommend leaving the dataset name the same as the default, which is the date of the survey, taken from the file information attached to your photos.

The screenshot shows the 'Data set details' screen with the subtitle 'Just a few details about what you are uploading...'. It contains three input fields: 'Choose Site' with a dropdown menu showing 'Claire\_Test', 'Dataset capture date' with a date picker set to '20/01/2017', and 'Dataset name' with a text field containing '20 Jan 2017'. A yellow 'NEXT →' button is at the bottom right.

Next you will be prompted to select an 'Output Profile'. An output profile is either a Survey or an Inspection. Surveys use the geotag information in your photos to produce a 3D model of your site which can then be queried for volume estimates, point surveys and line surveys.


Inspections also produce a 3D model of your site which can be visualised but does not include the same query options as a Survey. Inspections are usually faster to process.

In the future, requests to reprocess an Inspection as a Survey may incur an additional charge. So if you think you will need to query your model for point elevation, line surveys or volume surveys in the future, please select "Survey".


The screenshot shows the 'Choose Outputs' screen with the subtitle 'What do you want us to produce?'. It features a 'Select Output Profile' dropdown menu with 'Survey' selected. Below this, there are two columns of options: 'On the Propeller Viewer' (listing Orthomosaic, Digital Elevation Model, Point Cloud, and Source Photo Inspection View) and 'As Downloadable Files' (listing Orthomosaic GeoTIFF, Orthomosaic JPEG, Digital Elevation Model GeoTIFF, Terrain Trimesh DXF, and 3D Model OBJ with Texture). A yellow 'NEXT →' button is at the bottom right.

## Enter ground control point data

Click the "Upload Data" button at the top right hand side of the Viewer.




Select 'Start' to begin the upload process.



The first step requires to you to upload details of your ground control points, if you have them, along with details of the coordinate reference system and projection of your data.

If you are using AeroPoints, change "Select type" to "Propeller AeroPoints"


If you are not using any ground control, change "Select type" to "No GCPs or AeroPoints"



# Guidelines for ground control point files

If you are using your own ground control points, you will be prompted to upload a CSV (comma separated value) file with the coordinates and names of the GCPs.

You will also need to enter details of the Coordinate Reference System and projection of the GCPs. If you are uncertain about the coordinate reference system and projection please check with your surveyor before uploading. Our manual data processing step requires correct information.



## GCP rows and columns

Your ground control point file must include the following columns:

ID	Easting/Longitude	Northing/Latitude	Elevation

We recommend using at least 10 ground control points, even for small sites.


## Decimal places

- If you are using Eastings and Northings, they must have at least 3 decimal places.

- If you are using Longitude and Latitude, they must be formatted as decimal degrees with at least 8 decimal places.

## Uploading data with an AeroPoint survey


If you are using AeroPoints, please ensure that you have uploaded data from your AeroPoints and that it has been processed. You can process your AeroPoints in the AeroPoints Dashboard.

A screenshot of a mobile application interface titled "Ground control points". It features a "Select type" dropdown menu with "Propeller AeroPoints" selected. Below it is a "Select the corresponding AeroPoint Survey" dropdown menu with the placeholder text "Type to start searching...". A link "Can't find your AeroPoint Survey?" is visible below the second dropdown. A "SUBMIT →" button is at the bottom right.

## Uploading data without ground control points


If you want to proceed without Ground Control Points, select "No GCPs or AeroPoints" from the drop down menu.

You need to select the checkbox to acknowledge that your survey accuracy will be reduced without GCPs.

A screenshot of the same "Ground control points" screen. The "Select type" dropdown now shows "No GCPs or AeroPoints". Below it, a message states "Your accuracy is reduced" followed by a warning box: "A Survey that does not use Ground Control Points will have a reduced accuracy." with a checked "Got it!" checkbox. A "SUBMIT →" button is at the bottom right.

## Upload status

Make sure you leave your browser open while the Survey is uploading.




## Service Level Agreement

The confirmation screen indicates how long you should expect to wait for your survey to be finished processing.

There are a number of automatic processing steps that take time for our computers to process, as well as manual processing steps that may be required to correct errors that can arise when joining data from multiple flights, and potential errors resulting from the drone flight method.

If you used AeroPoints, we include an estimate of the time required to collect correction data from our correction network.

The Service Level Agreement reported at the bottom of the confirmation screen is the timeframe within which we commit to processing your data and is calculated as follows:



- Survey baseline SLA: 24 h
- If ground control points were used: + 12h (manual input required)
- If AeroPoints were used, and at time of submission they were unprocessed, we need to wait for correction data: +48 h
- If data is submitted just prior to a weekend of public holiday, this time is included in the SLA estimate.

## Uploading custom data

### Design surface (DXF, DWG, OrthoTIFF)

Design surfaces allow you to make measurements against the features in the uploaded file, for example using the Volume Compare measurement tool.

[Upload a design surface](#) to a Site by emailing [data@propelleraero.com](mailto:data@propelleraero.com) with a DXF, DWG or OrthoTIFF file, as well as the coordinate reference system and projection of the file.

### Overlay (KMZ, KML, GeoJSON, CZML)

You can drag and drop a custom layer file into the Viewer using the upload layer button in the Layers tab.

If you are uploading a KML or KMZ file, you must have the following settings for the polylines within the KML files, to ensure the Viewer can render it correctly:

- Altitude: Clamp to ground
- The file size must be less than 3 MB.

Only KML, KMZ, GeoJSON and CZML

+ Upload Layer

files can be accepted.


KML and KMZ files use the WGS84 Spherical Mercator (aka Web Mercator) coordinate reference system (EPSG 3785) by definition in their file format. This uses the WGS84 ellipsoid, the same as the Google Earth base map in the Viewer.

By default our Viewer displays the KML or KMZ at the height of the WGS84 ellipsoid / Google Earth base map.

By contrast, your Site is displayed at the height of the Geoid defined by your site's coordinate reference system.

To match the KMZ to your Site's geoid, instead of the WGS84 ellipsoid, select the "Clamp to ground" button that appears in the layers tab after selecting the KML or KMZ file.

Note that this "Clamp to ground" option is different to the "Clamp to ground" option in the altitude settings of your KML files. However, both are required for the Viewer to display your KML properly.



## Downloading data

### Where to download data


You can download survey data from the Layers Tab. You can download original source photos from the Photo View.

Click on Layers > Downloads to access downloadable data items including the 3D model, DEM, Contours, Ortho TIF,



LAZ, DXF, Ortho JPG files, and any custom KMZ files you uploaded.

You can download individual photos by selecting the Photo View > Photo Options button in the top right hand corner of the Photo View.



## Coordinate Reference System and Projection of downloaded data

The coordinate reference system and projection of downloads from the Layers tab is indicated next to the name of each downloadable item. The EPSG code indicates the coordinate reference system and projection. You can look up the EPSG code at [www.epsg.io](http://www.epsg.io) to get the details of the coordinate reference system and projection of the data item. By default, this will be the same as the EPSG code specified when you uploaded your survey data.

The KMZ file always has a code of "EPSG 3875: WGS84 Spherical Mercator" (aka Web Mercator). This is defined by the file format so cannot be changed.

## Downloads from the Layers Tab

By default you can download the following formats:

Data type	File type	Notes	Coordinate Reference System (CRS)
Orthophoto	GeoTIFF		WGS84
Orthophoto	GeoTIFF		Customer CRS
Orthophoto	JPEG	Maximum resolution	Customer CRS
Orthophoto	JPEG	5000 pixel resolution (along longest side)	Customer CRS



DEM	GeoTIFF	Digital Surface Model (Unfiltered)	WGS84
DEM	GeoTIFF	Digital Terrain Model (Filtered)	WGS84
DEM	GeoTIFF	Digital Surface Model (Unfiltered)	Customer CRS
DEM	GeoTIFF	Digital Terrain Model (Filtered)	Customer CRS
TIN	DXF	500000 Face Count	Customer CRS
TIN	DXF	250000 Face Count	Customer CRS
TIN	DXF	100000 Face Count	Customer CRS
Point Cloud	LAZ	Includes ground classification data from filtering.	Customer CRS
3D Model	OBJ	Textured	None

You can also download any custom KML or KMZ overlay files that you uploaded to your Site.

### **Orthophoto (.JPG )**

This is a single complete image of the orthomosaic in the widely supported JPG format. There are a number of sizes generated. The JPEG file format limits the resolution of a single file to 65k x 65k pixels, which means the resolution of this file may be lower than the full resolution ortho .TIF file.

The download zip file includes a .JGW world file in the site's defined CRS, or by default in a UTM projection.


### **DEM (.TIF )**

This is a GeoTIFF file version of the dataset Digital Elevation Model. This is available in the Site's defined CRS or in a geographic WGS84 projection.

## **TIN (.DXF) Surface 3D Faces**

DXF is a widely supported Autodesk format. The 3D Faces DXF format is used for surfaces.

The DXF files that we produce are made available for download in three different sizes (large, medium and small), with a faces count of 500K, 250K and 100K respectively. The DXF files have limits to the faces count in these downloads so that these files are usable sizes in desktop programs. This means for very large sites there will be some loss of data. For higher detail of smaller areas, you can download the point cloud .LAZ file in your preferred desktop software to create surface files.



## **Point Cloud (.LAZ)**

Propeller's core photogrammetry process produces a coloured point cloud, and this is the basis of the online and downloadable surface data outputs.

This download includes the ground classification data from Propeller's automated filtering process.

This file will be in the site's defined CRS (coordinate reference system), or in a UTM projection by default.

Note that a LAZ is a compressed LAS file, which is a standard point cloud format originally defined for use in laser scanning, and widely supported in desktop programs.



### **3D Model (.OBJ)**

This is a textured 3D model in the OBJ file defined by Wavefront format.

This file has no coordinate system defined.

This file can be used in applications that use textured 3D models such as virtual or augmented reality applications.





### **.TIF Orthomosaic**

This is a full resolution GeoTIFF file version of the dataset orthomosaic. This will be in the site's defined CRS, or by default in a geographic WGS84 projection.

### **Custom .KML and .KMZ files**

If you uploaded KML or KMZ files these will be available for download in the Layers Tab. The KMZ file always has a code of "EPSG 3875: WGS84 Spherical Mercator" (aka Web Mercator). This is defined by the file format so cannot be changed.

# Making measurements

The first step in making measurements is to create an Annotation using one of the three Annotations tools - point, line and polygon. After making an Annotation, you can select it from the list to view the different measurement tools available for that type of Annotation. The measurement tools are clickable and allow you to visualize the data and results of your measurements in the Map View.




If you create your Annotations in the Map View, you can download them later as a CSV. If you create Annotations in the Photo View, you can download them later as a PDF.

## Annotations

There are three types of Annotations - point, line and polygon. Each type of Annotation provides different types of Measurement Tools, which allow you to display data and data visualizations on your Site.


### Tools for creating Annotations

There are three tools for creating annotations. Each type of annotation provides different types of measurements.

Point annotations provide access to point measurements like elevation, position (lat/long), and elevation charts over time.	
Line annotations provide access to line measurements like horizontal and surface length, gradient, minimum and maximum elevation, and cross sections.	
Polygon annotations provide access to area and volume measurements like smart volume, reference level volume and volume comparison tools; minimum and maximum elevation; and horizontal and surface area.	

## Editing and Deleting Annotations

To edit an Annotation, select it from the list, and click the pencil icon which appears next to its name in the Map View.



To delete an Annotation, select it from the list, and click the bin icon from the list or the Map View


## Measurement Tools

Measurement Tools appear when you select an Annotation from the list, and can be clicked to show a visualization in the Map View. When clicked, the outline of the Measurement Tool will be blue:




## Site Tools

You can "promote" an annotation to Site level which means it will be available on all Datasets within a Site. To do this, click on the star next to the annotation.




## Point Tools

The location tool identifies the point elevation and latitude/longitude of the location where the annotation was made




The elevation tool displays elevation changes at a point over time, by comparing the elevation across multiple datasets.



## Line Tools

The horizontal length tool shows point to point distance between the endpoints of a line annotation.

Surface length is the length accounting for changes in elevation, and should be longer than horizontal length except on perfectly flat surfaces.



The gradient tool shows the minimum and maximum gradient along the segments defined by the control points used to create your line annotation.

If your line annotation only has two control points - one at the beginning and one at the end - the segment max and segment min will be the same and equal to the gradient over the whole line.

#### Gradient

Segment Max: 1.4 %  
Segment Min: 0.3 %

The line elevation tool shows minimum and maximum elevation along the line.


#### Elevation

Max Elevation: 9.137 m  
Min Elevation: 8.027 m

The cross section tool shows a cross section along the line annotation for a particular date/datasets..

You can compare multiple dates/datasets to the cross section tool by selecting "+Add" from the bottom right of the tool.

#### Cross Section (m)



15 June 2017

+ Add

## Volume and Area Tools

The volume tool has a number of different options including:

- Smart Volume
- Reference Level Volume
- Volume Compare

You can change the type of the volume

#### Smart Volume

Fill -17.489 m<sup>3</sup>    Net 1.945 m<sup>3</sup>    Cut 19.434 m<sup>3</sup>







measurement tool by selecting the drop down menu next to the name of the volume tool.

You can change the units from metres to feet by selecting the weight symbol in the bottom right of the tool.

The default volume measurement tool is the Smart Volume tool.


Smart Volume estimates the ground level from the features inside the annotation before calculating the Cut and Fill volume.




When Reference Level Volume is selected, you can enter a reference level to act as the base level of the volume being measured.

The Cut and Fill will then be calculated using this reference level as the base of the volume being measured.

Make sure to enter the reference level in the same units as the Volume calculation.








When Volume Compare is selected, you can change the date using a drop down menu to compare the Cut and Fill volume over time.

If you want to view multiple dates concurrently, you can add extra volume tools to the annotation by using the "+Add/Edit Items" button and selecting another volume tool.

The Map View will show the point cloud for the currently selected volume tool (highlighted with a blue outline).

If you have uploaded a design surface (DXF, DWG or OrthoTIFF), you can select this from the drop down menu as the surface against which to compare your volumes.

The elevation tool shows the maximum and minimum elevation within the selected region.



The horizontal area tool shows the area of the selected region as a flat plane.

The surface area tool shows the area of the volume including differences in surface elevation over the selected region.

Horizontal Area


637.597 m<sup>2</sup>

Surface Area


643.133 m<sup>2</sup>

## Tools for exporting data

Annotations which are created from within the Map View can be exported as a CSV (comma separated value) file.



Annotations which are created from within the Photo View can be exported as a PDF file.



An option to export will be greyed out if there were no annotations created in the correct View for export in that format.